Procedure name (Procedure code)			General Vessel Information Correction (VBY)																	
				ute	jth	at 1	at 2				С	ondit	1							
No.	Column	Field name	ID	Attribute	Length	Repeat 1	Repeat 2	Correction			Deletion				Forced deletion				Code	Input Condition/Format
1		Input Common Field	-	an	398			м			М			N	л					
2		Function Type Code	MDC	an	1			м			м			N	л					5: Correction 1: Deletion D: Forced deletion (Only customs can enter this data.)
3		Vessel Code	VEC	an	9			м			м			N	и				Call sign	Enter the call sign, Vessel Number or Fishing Boat Registration Number. * When entering the Fishing Boat Registration Number, add "@" at the beginning of the number and delete "-".
4		IMO Number	ΙМΟ	an	7			с			-				-				Lloyd's code	Enter the IMO Number excluding "IMO". * To use in "Vessel Arrival Report", enter IMO Number (Lloyd's code).
5		Fishing Boat Registration Number	RCO	an	9			с			-				-					Enter this number by deleting "-".
6		Vessel Name	VNA	an	35			м			-				-					
7		Vessel Name Replacement Date	VND	n	8			с			-				-					Enter the date to change the Vessel Name.
8		Vessel Type Code	vsc	an	5			м			-				-				Vessel Type Code	Vessel Type Code
9		Nationality Code of Vessel	VNC	an	2			м			-				-		Ī		UN/LOCODE (Country name: 2 digits)	UN/LOCODE (Country name: 2 digits)
10		Port Code of Vessel Registry	REG	an	5			м			-				-				UN/LOCODE	UN/LOCODE
11		Port Name of Vessel Registry	SKM	an	20			с			-				-					 Mandatory input if "ZZZ" is entered in [Port Code of Vessel Registry] (last 3 digits). Non-Enterable if "ZZZ" is entered in [Port Code of Vessel Registry] (last 3 digits).
12		Gross Tonnage	GTN	n	9			м			-				-					 Enter either: Gross Tonnage listed in the International gross tonnage certificate or Gross Tonnage listed in the vessel nationality certificate. Integer: 6 digits / Decimal: 2 digits
13		Net Tonnage	NTN	n	9			м			-				-					Integer: 6 digits / Decimal: 2 digits
14		Cruising Speed	NSP	n	4			с			-				-					 Enter the maximum cruising speed (Knot) Integer: 2 digits / Decimal: 1 digit
15		Vessel Length Overall	VLF	n	6			С			-				-					 Enter the length overall (meter). Integer: 2 digits / Decimal: 1 digit To use this data in [Line (Service) Report], enter the Vessel Length Overall if one of the following Vessel Types is selected: "1: Large vessel (except vessels loaded with dangerous goods)" "2: Large vessel and vessel loaded with dangerous goods" To use this data in [Line (Service) Report] and if the vessel passes through the Irako Channel or the Mizushima Line, enter the Vessel Length Overall if one of the following Vessel Types is selected: "3: Vessel loaded with dangerous goods" "5: Other"
16		Dead Weight Tonnage	JRT	n	9			с			-				-					Integer: 6 digits / Decimal: 2 digits
18		Vessel Owner Code	VOC	an	4			с			-				-				Carrier Code for NACCS	Carrier Code for NACCS * To enter a dummy code in [Vessel Owner Code], enter the Vessel Owner Name.
19		Vessel Owner Name	VON	an	70			с			-				-					 (1) If the vessel owner is not registered in the system, enter the Vessel Owner Name. (2) If the vessel owner is registered in the system, do not enter the data. * To enter a dummy code in [Vessel Owner Code], enter the Vessel Owner Name.

Procedure name (Procedure code)		General Vessel Information Correction (VBY)																	
	u			te	ų	t 1	t 2				С	onditi	on						
Item No.	Column	Field name	ID	Attribute	Length	Repeat 1	Repeat 2	Correction		Deletion			Forced deletion				Code	Input Condition/Format	
20		Vessel Owner Address	SSJ	an	105			с			-			-					
21		Vessel Owner Country Code	SSK	an	2			с			-			-				UN/LOCODE (country name: 2 digits)	UN/LOCODE (country name: 2 digits)
22		Vessel Owner Telephone Number	SSD	an	20			с			-			-					
23		Vessel Owner Fax Number	SSF	an	20			с			-			-					
24		Vessel Operator Code	OPC	an	4			м			-			-				Carrier Code(NACCS Carrier Code)	NACCS Carrier Code
25		Vessel Operator Address	SUJ	an	105			с			-			-					 * To use this data in [Application for berth assignment], [Application for berth change], [Application to load/discharge dangerous goods], [Financial Security information] or [Report on the security information of ship], enter the Vessel Operator Address. * To use this data in [Shift Notice] and if the vessel operator (not registered in the system) does not have a Shipping Agent, enter the Vessel Operator Address.
26		Vessel Operator Country Code	SUK	an	2			с			-			-				UN/LOCODE (country name: 2 digits)	UN/LOCODE (country name: 2 digits) * To use this data in [Financial Security information] or [Report on The security information of ship], enter the Vessel Operator Country Code.
27		Vessel Operator Telephone Number	SUD	an	20			с			-			-					 * To use this data in [Application for berth assignment], [Application for berth change], [Application to load/discharge dangerous goods] or [Financial Security information], enter the Vessel Operator Telephone Number. * To use this data in [Shift Notice] and if the vessel operator (not registered in the system) does not have a Shipping Agent, enter the Vessel Operator Telephone Number.
28		Vessel Operator Fax Number	SUF	an	20			с			-			-			_		
29		Notes	KRN	an	70			с			-			-					

* Item No.17 is a missing number.