

Procedure name (Procedure code)			Vessel Operation Information Registration (VTX01)																													
Item No.	Column	Field name	ID	Attribute	Length	Repeat 1	Repeat 2	Condition																Code	Input Condition/Format							
								Registration				Correction Whole data				Correction Single port (Operation information - No limit)				Correction Single port (Operation information - Limit)						Deletion						
1		Input Common Field	-	an	398			M				M				M				M				M								
2		Function Type Code	MDC	an	1			M				M				M				M				M							9: Registration 5: Correcting total data 4: Correcting single port (No limit on operation information) 3: Correcting single port (Limit on operation information) 1: Deletion	
3		Vessel Code	VEC	an	9			M				M				M				M				M				Call sign	Enter the Call Sign, Vessel Number or Fishing Boat Registration Number. * When entering the Fishing Boat Registration Number, add "@" at the beginning of the number and delete "-".			
4		Domestic Port Calling Order at the Time of Correcting Single Port	UPI	an	1			X				X				M				M				-								
5		Call Name	CNM	an	50			M				M				M				-				-							If there is no Call Name, enter "NIL". * To use this data in [Prior Notification] or [Course Notification], enter either Call Name or Vessel Telephone Number.	
6		Vessel Telephone Number	VTN	an	20			C				C				C				-				-							* To use this data in [Prior Notification] or [Course Notification], enter either the Call Name or the Vessel Telephone Number. * To use this data in [Financial Security information] or [Report on The security information of ship], enter Inmarsat Telephone Number or the Vessel Telephone Number (if there is no Other Communication Methods).	
7		Inmarsat Telephone Number	ITN	an	20			C				C				C				-				-							* To use this data in [Financial Security information] or [Report on The security information of ship], enter the Vessel Telephone Number or the Inmarsat Telephone Number (if there is no Other Communication Methods).	
8		FAX	FAX	an	20			C				C				C				-				-							Enter the FAX Number of the vessel.	
9		Other Communication Methods	ORM	an	70			C				C				C				-				-							* To use this data in [Financial Security information] or [Report on The security information of ship], enter "Other Communication Methods" if there is no Vessel Telephone Number or Inmarsat Telephone Number.	
10		Coastal service shall be provided for the time being	NAI	an	1			C				C				C				-				-							0: No 1: Yes * To use this data in [Report on The security information of ship], enter "Coastal service shall be provided for the time being".	
11		Voyage Number (1)	V1N	an	10			M				M				M				M				M							The filer enters a value.	
12		Voyage Number (2)	V2N	an	10			C				C				C				-				-							The filer enters a value.	
13		Liner/Tramper Distinction	ROI	an	3			C				C				C				-				-							DLN: Oceangoing - Liner DTR: Oceangoing - Tramp	
14		Port of Origin Code	DEP	an	5			C				C				C				-				-				UN/LOCODE	UN/LOCODE * If the Port of Origin Code is not registered in the system, enter "5 digits including 'ZZZ'". * To enter a dummy code in [Port of Origin Code], enter the Port of Origin Name.			
15		Port of Origin Name	DEN	an	20			C				C				C				-				-							(1) If the last 3 digits of the Port of Origin Code is "ZZZ", enter this data. (2) If the last 3 digits of the Port of Origin Code is not "ZZZ" enter nothing. * To enter a dummy code in [Port of Origin Code], enter the Port of Origin Name.	
16		Date of Departure from Port of Origin	DED	n	8			C				C				C				-				-							YYYYMMDD	
17		Code for Foreign Port of Calling before Arriving at Domestic Port	P__	an	5	30		C				C				C				-				-				UN/LOCODE	UN/LOCODE * If "Code for Foreign Port of Calling before Arriving at Domestic Port" is not registered in the system, enter "5 digits including 'ZZZ'". * To enter a dummy code in "Code for Foreign Port of Calling before Arriving at Domestic Port", enter the Name for Foreign Place of Calling before Arriving at Domestic Port. * If this data is repeatedly registered, enter the last port of call in the last line.			
18		Name for Foreign Place of Calling before Arriving at Domestic Port	N__	an	20	*		C				C				C				-				-							(1) If the last 3 digits of "Code for Foreign Port of Calling before Arriving at Domestic Port" is "ZZZ", enter this data. (2) If the last 3 digits of "Code for Foreign Port of Calling before Arriving at Domestic Port" is not "ZZZ", enter nothing. * To enter a dummy code in [Code for Foreign Port of Calling before Arriving at Domestic Port], enter "Name for Foreign Place of Calling before Arriving at Domestic Port".	
19		Date of Arrival at Foreign Port of Calling before Arriving at Domestic Port	I__	n	8	*		C				C				C				-				-							YYYYMMDD	
20		Date of Departure from Foreign Por of Calling before Arriving at Domestic Port	S__	n	8	*		C				C				C				-				-							YYYYMMDD	

Procedure name (Procedure code)			Vessel Operation Information Registration (VTX01)																													
Item No.	Column	Field name	ID	Attribute	Length	Repeat 1	Repeat 2	Condition																Code	Input Condition/Format							
								Registration				Correction Whole data				Correction Single port (Operation information - No limit)				Correction Single port (Operation information - Limit)						Deletion						
21		Presence/Absence of Calling at Port Located in Polluted Area	K__	an	1	*		C				C				C				-									For international ships and inland waterway ships, specify Presence/Absence of Calling at Port Located in Polluted Area designated by WHO. 0: No 1: Yes			
22		Type of Certificate concerning Hygiene Management in Vessel	NSS	an	1			C				C				C				-									C: Control E: Control Exemption O: No Certificate			
23		Certificate Issuing Port Code concerning Hygiene Management in Vessel	NSC	an	5			C				C				C				-							UN/LOCODE	UN/LOCODE * To enter a dummy code in "Certificate Issuing Port Code concerning Hygiene Management in Vessel", enter "Certificate Issuing Port Name concerning Hygiene Management in Vessel". * If "C: Control" or "E: Control Exemption" is selected in [Type of Certificate concerning Hygiene Management in Vessel], enter "Certificate Issuing Port Code concerning Hygiene Management in Vessel".				
24		Certificate Issuing Port Name concerning Hygiene Management in Vessel	NSM	an	20			C				C				C				-									* To enter a dummy code in "Certificate Issuing Port Code concerning Hygiene Management in Vessel", enter "Certificate Issuing Port Name concerning Hygiene Management in Vessel".			
25		Date of Issuing Certificate concerning Hygiene Management in Vessel	NSD	n	8			C				C				C				-									YYYYMMDD * If any option except "O: No Certificate" is selected in [Type of Certificate concerning Hygiene Management in Vessel], enter this data. * If "C: Control" or "E: Control Exemption" is selected in [Type of Certificate concerning Hygiene Management in Vessel], enter "Date of Issuing Certificate concerning Hygiene Management in Vessel". * "Date of Issuing Certificate concerning Hygiene Management in Vessel" must be a date before today.			
26		Presence/Absence of Doctor in Vessel	SIU	an	1			C				C				C				-									0: No 1: Present			
27		Name of Doctor in Vessel	SIS	an	70			C				C				C				-									* Enter the Name of Doctor in Vessel, if any.			
28		Code for First Foreign Port of Calling after Departing from Domestic Port	EFC	an	5			C				C				C				-							UN/LOCODE	UN/LOCODE Enter "Code for First Foreign Port of Calling after Departing from Domestic Port". (1) If undetermined, enter "ZYZZZ". (2) If unknown, enter "ZZZZZ". * If a dummy code is entered for this data, enter "Name for First Foreign Port of Calling after Departing from Domestic Port". * To use this data in [Course Notification], enter "Cord for Domestic Place of Calling" for the vessel which has a port of destination. If it is not entered, enter "Code for First Foreign Port of Calling after Departing from Domestic Port". If neither is entered, enter "Final Destination Port Code".				
29		Name for First Foreign Port of Calling after Departing from Domestic Port	EFN	an	20			C				C				C				-									(1) If the last 3 digits of "Code for First Foreign Port of Calling after Departing from Domestic Port" is "ZZZ", enter this data. (2) If the last 3 digits of "Code for First Foreign Port of Calling after Departing from Domestic Port" is not "ZZZ", enter nothing. * To enter a dummy code in [Code for First Foreign Port of Calling after Departing from Domestic Port], enter "Name for First Foreign Port of Calling after Departing from Domestic Port".			
30		Final Destination Port Code	FDS	an	5			C				C				C				-							UN/LOCODE	UN/LOCODE Enter "Final Destination Code". (1) If undetermined, enter "ZYZZZ". (2) If unknown, enter "ZZZZZ". * If a dummy code is entered for this data, enter "Final Destination Port Name". * To use this data in [Course Notification], enter "Cord for Domestic Place of Calling" for the vessel which has a port of destination. If it is not entered, enter "Code for First Foreign Port of Calling after Departing from Domestic Port". If neither data is entered, enter "Final Destination Port Code".				
31		Final Destination Port Name	LSN	an	20			C				C				C				-									If the last 3 digits of "Final Destination Port Code" is not "ZZZ", enter nothing. * To enter a dummy code in [Final Destination Port Code], enter "Final Destination Port Name".			
32	9	Cord for Domestic Place of Calling	JPD	an	5			M				M				M				M							UN/LOCODE	UN/LOCODE (1) If "Correction of single port" is entered in [Function Type], some data must have been entered in "Japanese port of call" (first column) (2) If "Correction of single port" is entered in [Function Type], no data must have been entered in "Japanese port of call" (from the second column). * To use this data in [Course Notification], enter "Cord for Domestic Place of Calling" for the vessel which has a port of destination. If it is not entered, enter "Code for First Foreign Port of Calling after Departing from Domestic Port". If neither is entered, enter "Final Destination Port Code".				

Procedure name (Procedure code)			Vessel Operation Information Registration (VTX01)																											
Item No.	Column	Field name	ID	Attribute	Length	Repeat 1	Repeat 2	Condition																		Code	Input Condition/Format			
								Registration				Correction Whole data				Correction Single port (Operation information - No limit)				Correction Single port (Operation information - Limit)				Deletion						
32-1	*	Order of Calling at Domestic Ports	JPJ	an	1			M				M				M				M				-				(1) Enter "Order of Calling at Domestic Ports". (2) If the Function Type is "9" or "5", the order of the port of call must be a serial number from "1". Note: Enter "X" in [Order of Calling at Domestic Ports] if the port is skipped. However, you cannot correct the order of port of call if you correct the single port.		
33	*	Code for Vessel Arrival Purpose	IPO	an	3			C				C				C				C				-			Purpose code	Code for Vessel Arrival Purpose [Customs Station/Immigration]		
34	*	Identifier for Presence/Absence of Cargo on Board	SKU	an	3			C				C				C				C				-				48△: Cargo (Unloading) N48: Cargo (No unloading) 57△: No cargo		
35	*	Status Code for Cargo on Board	SK_	an	3	3		C				C				C				C				-			UN/GDS code	Cargo type code 10: Bulk 7: RORO cargo 6: Vehicles 8: Palette 9: Container 5: Other non-container [Captain of the Port/Port Management Body/Security Division]		
35-1	*	Date of Arrival at Port Area	KND	n	8			C				C				C				C				-				YYYYMMDD [Port Management Body/District Transport Bureau/Security Division]		
35-2	*	Time of Arrival at Port Area	KNT	n	4			M				M				M				M				-				HHMM [Port Management Body/District Transport Bureau/Security Division]		
36	*	(Estimated) Docking Place Code	RCC	an	5			C				C				C				C				-			Berth code	This data must be a berth code for "Oceangoing" and "Coastal". * To use this data in [Course Notification], enter "(Estimated) Docking Place Code" for any vessels arriving at/departing from Mizushima Port or Keihin Harbor (Yokohama District). If it is not entered, enter "(Estimated) Anchoring Place Code". * If some data has been entered in the application to use vessel operation information, use that value first. (The information of Unified Application Before Vessel Arrival for Captain of the Port/Port Management Body should be entered separately in the application operation.)		
37	*	(Estimated) Docking Date	RCD	n	8			C				C				C				C				-				YYYYMMDD * If some data has been entered in the application that uses the vessel operation information, use that value first. (The information of Unified Application Before Vessel Arrival for Captain of the Port/Port Management Body should be entered separately in the application operation)		
38	*	(Estimated) Docking Time	RCT	n	4			M				M				M				M				-				HHMM If "(Estimated) Docking Date" is entered, this data must be entered. (The information of Unified Application Before Vessel Arrival for Captain of the Port/Port Management Body should be entered separately in the application operation)		
39	*	(Estimated) Anchoring Place Code	BCC	an	5			C				C				C				C				-			Berth code	* To use this data in [Course Notification], enter "(Estimated) Docking Place Code" for any vessels arriving at/departing from Mizushima Port or Keihin Harbor (Yokohama District). If it is not entered, enter "(Estimated) Anchoring Place Code". * If some data has been entered in the application to use vessel operation information, use that value first. (The information of Unified Application Before Vessel Arrival for Captain of the Port/Port Management Body should be entered separately in the application operation)		
40	*	(Estimated) Anchoring Date (from)	BCD	n	8			C				C				C				C				-				YYYYMMDD * If some data has been entered in the application that uses the vessel operation information, use that value first. (The information of Unified Application Before Vessel Arrival for Captain of the Port/Port Management Body should be entered separately in the application operation)		
41	*	(Estimated) Anchoring Time (from)	BCT	n	4			M				M				M				M				-				HHMM format If "(Estimated) Anchoring Date (from)" is entered, this data must be entered. (The information of Unified Application Before Vessel Arrival for Captain of the Port/Port Management Body should be entered separately in the application operation)		
50	*	Departure Berth Place Code	OAC	an	5			C				C				C				C				-			Berth code	This data must be a berth code for "Oceangoing" and "Coastal". * To use this data in [Course Notification], enter "Departure Berth Place Code" for any vessels arriving at/departing from Mizushima Port or Keihin Harbor (Yokohama District).		
51	*	(Estimated) Anchoring Date (to)	BDT	n	8			C				C				C				C				-				YYYYMMDD Enter the data as follows: (1) (Estimated) Anchoring Date (from) ≤ (Estimated) Anchoring Date (to) (2) (Estimated) Docking Date ≤ (Estimated) Anchoring Date (to)		

Procedure name (Procedure code)			Vessel Operation Information Registration (VTX01)																								
Item No.	Column	Field name	ID	Attribute	Length	Repeat 1	Repeat 2	Condition															Code	Input Condition/Format			
								Registration			Correction Whole data			Correction Single port (Operation information - No limit)			Correction Single port (Operation information - Limit)			Deletion							
52	*	(Estimated) Anchoring Time (to)	BTT	n	4			M				M				M				M				-			HHMM Enter the data as follows: (1) (Estimated) Anchoring Date/Time (from) < (Estimated) Anchoring Date/Time (to) (2) (Estimated) Docking Date/Time < (Estimated) Anchoring Date/Time (to)
53	*	(Estimated) Leaving Shore Date	DCD	n	8			C				C				C				C				-			YYYYMMDD Enter the data as follows: (1) (Estimated) Anchoring Date (from) ≤ (Estimated) Leaving Shore Date (2) (Estimated) Docking Date ≤ (Estimated) Leaving Shore Date
54	*	(Estimated) Leaving Shore Time	DCT	n	4			M				M				M				M				-			HHMM Enter the data as follows: (1) (Estimated) Anchoring Date/Time (from) < (Estimated) Leaving Shore Date/Time (2) (Estimated) Docking Date/Time < (Estimated) Leaving Shore Date/Time
55	*	Shipping Agent Code	PGC	an	5			C				C				C				C				-		User Code	User Code If the agent is not registered in the system, enter "99999". * If "Shipping Agent Address" or "Shipping Agent Telephone Number" has been entered, enter "Shipping Agent Code" or "Shipping Agent Name". [Application to load/discharge dangerous goods/Application for berth assignment/Application for berth change/Application for moorings/Application for using moorings/Prior Notification/Financial Security information] *If "Shipping Agent Address", "Shipping Agent Telephone Number" or "Shipping Agent Fax Number" has been entered, enter "Shipping Agent Code" or "Shipping Agent Name". [Financial Security information]
56	*	Shipping Agent Name	PNN	an	50			C				C				C				C				-			(1) If the agent is not registered in the system, enter the name. (2) If the agent is registered in the system, enter nothing. * If a Shipping Agent that is not the reporter is used, enter "Shipping Agent Name". * If "Shipping Agent Address" or "Shipping Agent Telephone Number" has been entered, enter "Shipping Agent Code" or "Shipping Agent Name". [Application to load/discharge dangerous goods/Application for berth assignment/Application for berth change/Application for moorings/Application for using moorings/Prior Notification/Financial Security information] * Enter "Shipping Agent Code" or "Shipping Agent Name" if "Shipping Agent Address", "Shipping Agent Telephone Number" or "Shipping Agent Fax Number" has been entered. [Financial Security information]
57	*	Shipping Agent Address	PDD	an	74			C				C				C				C				-			* If a Shipping Agent that is not the reporter is used, enter "Shipping Agent Address". * If "Shipping Agent Telephone Number" has been entered, enter "Shipping Agent Address". * If "Shipping Agent Code", "Shipping Agent Name" or "Shipping Agent Telephone Number "has been entered, enter "Shipping Agent Address". [Application to load/discharge dangerous goods/Application for berth assignment/Application for berth change/Application for moorings/Application for using moorings/Prior Notification/Financial Security information] * If "Shipping Agent Code", "Shipping Agent Name", or "Shipping Agent Telephone Number "or "Shipping Agent Fax Number" has been entered, enter "Shipping Agent Address". [Financial Security information]
58	*	Shipping Agent Telephone Number	SDD	an	20			C				C				C				C				-			* If a Shipping Agent that is not the reporter is used, enter "Shipping Agent Telephone Number". * If "Shipping Agent Code", "Shipping Agent Name" or "Shipping Agent Address"has been entered, nter "Shipping Agent Telephone Number" . [Application to load/discharge dangerous goods/Application for berth assignment/Application for berth change/Application for moorings/Application for using moorings/Prior Notification] * If "Shipping Agent Code", or "Shipping Agent Name" has been entered, enter "Shipping Agent Telephone Number" . [Vessel Arrival Report] * If "Shipping Agent Code", "Shipping Agent Name", or "Shipping Agent Address" or "Shipping Agent Fax Number" has been entered, enter "Shipping Agent Telephone Number" . [Financial Security information]
59	*	Shipping Agent Fax Number	AFC	an	20			C				C				C				C				-			

Procedure name (Procedure code)			Vessel Operation Information Registration (VTX01)																											
Item No.	Column	Field name	ID	Attribute	Length	Repeat 1	Repeat 2	Condition																Code	Input Condition/Format					
								Registration				Correction Whole data				Correction Single port (Operation information - No limit)				Correction Single port (Operation information - Limit)						Deletion				
60	*	Landing Cargo Status Code at Estimated Port of Arrival	RK_	an	3	3	C					C				C				C				-			UN/GDS code	Cargo type code * To enter "Landing Cargo at Estimated Port of Arrival", enter "Landing Cargo Status Code at Estimated Port of Arrival". * If some data has been entered in the application operation, use the value of application operation first.		
61	*	Landing Cargo Name at Estimated Port of Arrival	RH_	an	70	*	C					C				C				C				-				* To enter "Landing Cargo at Estimated Port of Arrival", enter "Landing Cargo Name at Estimated Port of Arrival". * If some data has been entered in the application operation, use the value of application operation first.		
62	*	Landing Cargo Quantity (or Weight) at Estimated Port of Arrival	RR_	n	10	*	C					C				C				C				-				Integer: 7 digits / Decimal: 2 digits * To enter "Landing Cargo at Estimated Port of Arrival", enter "Weight, measurement or quantity of the landing cargo at Estimated Port of Arrival". * If some data has been entered in the application operation, use the value of application operation first.		
63	*	Landing Cargo Quantity Unit Code at Estimated Port of Arrival	RT_	an	3	*	C					C				C				C				-				(Weight) TNE: Ton (Measurement) MTΔ: M/T MTQ: Cubic meter (Quantity) NOΔ: Piece/Unit, etc. * If some data has been entered in the application operation, use the value of application operation first.		
64	*	Port of Loading Code for Landing Cargo at Estimated Port of Arrival	RM_	an	5	*	C					C				C				C				-			UN/LOCODE	UN/LOCODE If "Port of Loading Code for Landing Cargo at Estimated Port of Arrival" is not registered in the system, enter "5 digits including ZZZ". * To enter "Landing Cargo at Estimated Port of Arrival", enter "Port of Loading Code for Landing Cargo at Estimated Port of Arrival". * If some data has been entered in the application operation, use the value of the application operation first.		
65	*	Port of Loading Name for Landing Cargo at Estimated Port of Arrival	RN_	an	20	*	C					C				C				C				-				(1) If the port name (Port of Loading Name for Landing Cargo at Estimated Port of Arrival) is not registered in the system, enter the name. (2) If the port name (Port of Loading Name for Landing Cargo at Estimated Port of Arrival) is registered in the system, enter nothing. * If some data has been entered in the application operation, use the value of the application operation first.		
66	*	Loading Cargo Status Code at Estimated Port of Arrival	HK_	an	3	3	C					C				C				C				-			UN/GDS code	Cargo type code 10: Bulk 7: RORO cargo 6: Vehicles 8: Palette 9: Container 5: Other non-container * To enter "Loading Cargo at Estimated Port of Arrival", enter "Loading Cargo Status Code at Estimated Port of Arrival". * If some data has been entered in the application operation, use the value of application operation first.		
67	*	Loading Cargo Name at Estimated Port of Arrival	HH_	an	70	*	C					C				C				C				-				* To enter "Loading Cargo at Estimated Port of Arrival", enter "Loading Cargo Name at Estimated Port of Arrival". * If some data has been entered in the application operation, use the value of application operation first.		
68	*	Loading Cargo Quantity (or Weight) at Estimated Port of Arrival	HS_	n	10	*	C					C				C				C				-				Integer: 7 digits / Decimal: 2 digits * To enter "Loading Cargo at Estimated Port of Arrival", enter "Weight, measurement or quantity of the landing cargo at Estimated Port of Arrival". * If some data has been entered in the application operation, use the value of application operation first.		
69	*	Loading Cargo Quantity Unit Code at Estimated Port of Arrival	HT_	an	3	*	C					C				C				C				-				(Weight) TNE: Ton (Measurement) MTΔ: M/T MTQ: Cubic meter (Quantity) NOΔ: Piece/Unit, etc. * If some data has been entered in the application operation, use the value of application operation first.		
70	*	Using Carrier Code	R__	an	4	20	C					C				C				C				-			NACCS shipping company code	Enter the Using Carrier Code which will submit the manifest in the case of a jointly operated vessel.		
71	*	Identifier of Belongings/Consignment Articles	KTC	an	2		C					C				C				C				-				YY: With customs clearance of belongings/with customs clearance of consignment articles YN: With customs clearance of belongings/without customs clearance of consignment articles NY: Without customs clearance of belonging/with customs clearance of consignment articles NN: Without customs clearance of belonging/without customs clearance of consignment articles		
72	*	Remarks	SKJ	an	140		C					C				C				C				-				[Customs Station]		

* Item No.42 to 49 are missing numbers.